



WORKHORSE PRODUCTS

3730 East Southern Avenue

Phoenix, AZ 85040

Phone 800-778-8779


Fax 602-437-2270

www.workhorseproducts.com

support@workhorseproducts.com

WORKHORSE WASH-IT Screen Wash-Out / Reclaim Sink

Assembly No. 11506



P/N 67-1420 rev.5.05

Introduction

Congratulations on your purchase of the **WASH-IT Screen Wash -Out / Reclaim Sink** from WORKHORSE PRODUCTS.

Check the Boxes for damage, DO NOT accept boxes if damaged due to improper handling during shipping. Report any damage to the Carrier at once as well as WORKHORSE at 800-778-8779.

Inspect the Boxes and contents IMMEDIATELY while the carrier is still there. Our packaging has been carefully designed to handle normal shipping conditions. However, we cannot be responsible for shipping damage by the carrier. Upon discovery of freight damage, notify driver AND note damage on all paperwork! File a claim with the carrier, then notify WORKHORSE at 800-778-8779.

Read Instructions first

First read the instructions completely before you attempt to assemble the Product, this will familiarize you with the parts and the sequence of assembly.

Features

- Ideal for small and medium sizes shops.
- Sturdy construction
- Translucent back splash window.
- Large screen capacity
- Water-proof welded Seams
- Adjustable screen tray
- Standard plumbing fitting
- Easy / Thorough draining
- Can be shipped by UPS and is easy to assemble.

Contents

- Page 2 Parts List, shipping boxes, photo of all parts out of box
 Page 4-7 Assembling the Wash-It Sink.
 Page 7 Available accessories.
 Page 8 Limited Warranty and Warranty Registration Form

Please take a moment and fill out the following information:

Serial Number: _____ **Date of Purchase** _____ **Product Name** _____
Company Purchased from _____ **Assembled by** _____

Please keep this information in a safe place for future reference


The Wash Sink ships in one box.

Use the next two photos to verify you have all the parts.



1. The Box contains:

- A -Two Side Splash panels
- B -One Top Splash panel
- C -Two Screen Stops
- D -Bag of Nuts and Bolts
- E -Four Wash Sink Legs
- F -One Back Leg brace and two Side Leg Braces
- G- One Sink Base
- H- One Plexiglass Back Panel



4 Leg Leveling Feet

Bag of 1/2" Nuts

Bag of 1/2" Washers

Bag of 1/2" Bolts

Tube of Silicone to seal
Bolts and Seams.

Drain assembly (drain, nut and seal)



*** Not Shown ***

Assembling Wash Sink / Photo 1/2

Take the Four Leveling Feet and screw the Jam Nut all the way down to the foot.

Then Screw into the Bottom of the Legs. (photo 1)

Four Leveling feet installed (Photo 2)



Assembling Wash Sink / Photo 3

Remove the Back Splash Translucent Panel from the Wash Sink Base.



Assembling Wash Sink / Photo 4

Once you have the Leveling feet attached turn the Wash Sink base upside down and place one of the Legs in a corner with the smooth sides facing out..

Put in a Bolt and then a Lock washer then the Nut and tighten by hand.



Assembling Wash Sink / Photo 5

Complete putting on both back or front Legs with the nuts and bolts tightened only by hand.



Assembling Wash Sink / Photo 6

Once you have two back or front Legs attached place one of the shorter braces between them with the smooth side facing out.

Put in the four Bolts, washers and Nuts and tighten by hand.

Once you have all the Bolts, Lock Washers and Nuts in place tighten with a 1/2 wrench.



Assembling Wash Sink / Photo 7

When all Four Legs are on turn the Wash Sink base the long way and put the longer Brace between the two BACK legs.

NOTE: The back of the Wash Sink has the Shorter Lip.

Tighten the Bolts. Then check to see all the Bolts for the Legs and braces are tightened.



Assembling Wash Sink / Photo 8

Once all the Legs and Braces are on turn over the wash sink and place on the floor.

Then take one of the two Side Splash Panels and put it into one of the corners.

Push the panel all the way down inside of the Wash Sink Base (insert Photo).

The shorter side of the L Shaped Panel faces to the center of the Wash Sink Base.



Assembling Wash Sink / Photo 9

Put the other Side Splash Panel so both shorter ends face the center. Tighten Bolts by hand.



Assembling Wash Sink / Photo 10

Once you have installed both back L Shaped Back Splash Panels, take the Translucent Back Splash Panel and insert into the slots provided on the Translucent Back Splash Panel

Push the panel all the way down to the Lip on the Wash Sink Base.

Tighten the Bolts with a 1/2" wrench.



Assembling Wash Sink / Photo 11

Put the Top Splash panel on. The lip that sticks up goes in the back and faces up. (see Insert Photo).

Line up bolt holes and insert Bolts. (three on each side). Tighten by hand till all Bolts installed then tighten with 1/2" wrench.



Assembling Wash Sink / Photo 11

When you have the Wash sink completely assembled use the tube of Silicone Sealer and seal all the Bolts and seams from the inside of the Wash Sink.



Assembling Wash Sink / Photo 12

When you have the Wash sink completely assembled, place it where you will use it and have your plumber install the drain.

Once drain is in place the Screen Stand-up racks in the bottom of the Wash Sink base.



AVAILABLE: Squeegee Rack

OPTIONAL SQUEEGEE RACK

You can add this handyrack to your Wash-it sink. It simply hangs on the inside and holds 8 squeeeges.

Part No:11534

Please call for details and pricing
1-800-778-8779



LIMITED WARRANTY AND WARRANTY REGISTRATION

Although every effort has been made to provide accurate specifications, Workhorse Products/Odyssey does not assume any liability for damages, whether consequential or incidental, that may result from the use or misuse of the indicated specifications. Workhorse Products/Odyssey requires the use of a licensed industrial electrician for the installation of electrical service to equipment requiring electrical power.

Workhorse Products/Odyssey reserves the right to alter specifications in the manufacture of its products.

It is understood and agreed that Seller's liability for any equipment whether liability in contract, in tort, under any warranty, in negligence, in strict liability or otherwise shall not exceed the return of the amount of the purchase price paid by Buyer. Notwithstanding the foregoing provision, under no circumstances shall Seller be liable for special, indirect or consequential damages. The price stated for the equipment is a consideration in limiting Seller's liability. No action regardless of form, arising out of the transactions under this Agreement may be brought by Buyer more than one (1) year after the cause of action has occurred. Our warranty is specified is exclusive and no other warranty, whether written or oral, is expressed or implied. Workhorse Products specifically disclaims the implied warranties of merchantability and fitness for a particular purpose.

Equipment manufactured or sold by Workhorse Products/Odyssey is warranted against defects in workmanship and materials for a period of one year from receipt by customer. All warranties initiate from date of shipment to original customer.

Replacement parts are covered for the term of the equipment warranty period. Parts not under warranty are covered for thirty (30) days from receipt by customer. Any part found by Workhorse/Odyssey to be defective in material or workmanship within the stated warranty period will be replaced or repaired at Workhorse's option without charge. **AFTER OBTAINING AN RMA# SHIP FREIGHT PREPAID TO 3730 E. Southern Avenue, PHOENIX, AZ 85040 USA.** Written authorization must be obtained from Workhorse/Odyssey before any part will be accepted. Replacement parts are sent out freight collect. **Parts sent out prior to receiving defective part will be sent C.O.D., cost plus freight. Upon return of defective part, if it is deemed that the part was not damaged by customer but failed, the cost of the replacement part will be refunded.**

This warranty does not extend to expendable parts such as filters, fuses, elements and brushes. Workhorse does not warrant failure of parts or components resulting from misuse or lack of proper maintenance. Installation, inspection, and maintenance costs are the sole responsibility of the purchaser.

Registration Form

Company Name: _____	Contact Name: _____
Address: _____ _____	Phone Number: _____
City: _____	Fax Number: _____
State: _____	Email : _____
Country: _____	Cell Number: _____
Zip Code: _____	Serial Number: _____
Model Number: _____	Date Recived: _____
Date Purchased _____	

11506

Please Fax Registration Form for warranty to take place